ENSC 388: Engineering Thermodynamics and Heat Transfer

Experiment 2: Vapor Compression Refrigeration Cycle

Objective

Determining the coefficient of performance of a vapour compression refrigeration cycle.

Apparatus


Figure 1 shows the experimental setup in details. Key components in the refrigeration system are a compressor, a condenser, an evaporator and an expansion valve. The compressor unit shown in Fig. 2 comprises an encapsulated, fully hermetic reciprocating compressor with an integrated drive motor. Such compressors are used in regular refrigerators.

The condenser is a glass container with a cooling coil through which water flows (see Fig. 3a). The gaseous refrigerant is pumped into the container by the compressor, here it condenses and collects in the bottom of the container. Heat is drawn off via the water circulating in cooling coil in the container.

The evaporator shown in Fig. 3b, similar to the condenser, includes a glass container and a copper coil through which water flows. In this case, the water is not used for cooling; conversely, it generates the cooling load. The refrigerant expands in the evaporator and changes from the liquid to vapor.

The system has an expansion valve which is a float valve. Schematic of the expansion valve is shown in Fig. 4. Once the refrigerant collecting in the condenser reaches a certain level, the float (1) lifts the needle (2) from its seat, and opens the connection to the evaporator. The injection of the refrigerant into the evaporator is controlled by the expansion valve.

When the system is started, the air in the system has to be released using the bleed valve. For this purpose the valve (item 20 in Fig. 1) is opened several times for a few seconds after the compressor is started, until the clearly detectable odour of escaping gas indicates that there is no more air in the system.



1	Table Support	12	Flow meter, Hot Water
2	Water Connections	13	Sight Glass
3	Temperature Measurement Point	14	Evaporator
4	Condenser	15	Pressure Display, Evaporator
5	Expansion Valve	16	Power meter, Compressor
6	Hand Valve	17	Switchable Temperature Display
7	ON-OFF Switch, Compressor	18	Flow meter, Refrigerant
8	Compressor	19	Pressure Display, Condenser
9	Filling Connection	20	Bleed Valve
10	Emergency Stop Button	21	Pressostat
11	Master Switch	22	Flow meter, Cooling Water

Figure 1- Components of experimental apparatus



Figure 2- Compressor unit




Figure 3- a) Condenser and b) Evaporator of the system.




Figure 4- Schematics of the expansion valve.

The system is equipped with 8 thermometers. The positions of the measuring points are marked with their numbers on the front panel of the system; these numbers correspond to the following points:

- = Cold water inlet, condenser
- = Cold water outlet, condenser
- = Hot water inlet, evaporator
- = Hot water outlet, evaporator
- = Mean temperature, evaporator
- = Refrigerant temperature, outlet of compressor
- = Mean temperature, condenser
- = Temperature after expansion valve

The measured data collected during the operation of the system enables one to calculate the thermal characteristics of the system to be calculated.

Filling and draining the system

The system is to be filled until the glass container for the evaporator is half full (Fig. 1). The hand valves 1 - 3 are open during the filling process, hand valve 4 is closed.

- Fit suitable hose to the filling connection (9) and insert into the container in which the refrigerant is supplied such that refrigerant can be drawn out.
- Start the compressor, a partial vacuum is formed in the evaporator such that the refrigerant is drawn out of the container
- Continue filling process until the evaporator is half full with the liquid phase of the refrigerant
- Close the hand valve 2, remove the hose
- Switch off the compressor

The compressor is filled with oil on assembly in the factory; this filling is sufficient for its lifetime. Due to the fully hermetic construction, no more oil can be added during later operation. However, during its operation oil droplets enters the refrigerant circuit. When the system is switched off, the majority of the refrigerant and some oil gather in the evaporator. The oil is returned in the following way:

- Hand valves 2 and 3 must be closed
- Hand valves 1 and 4 must be open
- Switch on compressor, the liquid is drawn from the compressor through the capillary tube to the compressor and from there pumped to the condenser
- When the contents of the container have been drawn out, stop the process, for this purpose close valve 4 and open valve 3; in this way the system is again in normal operation

For draining the system

- Switch off the compressor
- Fit the hose to the filling connection and place it in the container
- Open all hand valves except valve 4
- Open bleed valve (item 20 in Fig. 1), the refrigerant slowly returns to the container

Theory

The basis of refrigeration systems is a thermodynamic cycle working between two different temperature sources. In this cycle a refrigerant (e.g. R134a) passes through various changes of state in a defined sequence and returns to its initial state. A refrigerator is a machine that removes heat from a low temperature region. Since energy cannot be destroyed, the heat taken in at a low temperature must be dissipated to the surroundings. The Second Law of Thermodynamics states that heat will not pass from a cold region to a warm one without spending energy or work. Therefore, a refrigerator requires energy input for its operation. It should be noted that heat pump and refrigeration cycles are the same, but in the

case of the heat pump the heat emitted is utilised where in the case of a refrigeration system the amount of absorbed heat is beneficial.

One of the common refrigeration systems in use today is the Vapor Compression Cycle. Schematic of a vapour compression refrigeration cycle is shown in Fig. 5; this cycle has the following component:

- A compressor which compresses the vaporous working fluid and providing required mechanical energy, \dot{W} , to the system
- The condenser that absorbs heat (at constant pressure) from the working medium and transfer it to the high temperature source
- An expansion (throttling) valve that expands the liquid working medium during a constant enthalpy process
- An evaporator facilitates the evaporation of the working medium while it absorbs heat from the low temperature reservoir




Figure 5- Schematics of a vapor compression refrigeration cycle.

For thermal analysis of refrigeration cycle several diagrams such as T - s or p - h diagrams can be used. The pressure diagram of an ideal refrigeration cycle shown in Fig. 6, includes the following processes:

- 1-2: Isentropic compression to the final compression temperature with superheating of the working medium, adiabatic
- 2-2': Isobaric cooling to the condensation temperature
- 2'-3: Isobaric condensation, releasing the condensation enthalpy
- 3-4: Expansion in the wet vapour region,
- 4-1 :Isobaric evaporation, absorption of the evaporation enthalpy

The key difference between the real cyclic process and the ideal cyclic process is that compression is not isentropic. Thus more work must be expended at the compressor to achieve the same final pressure. In

addition superheating of the refrigerant is necessary prior to compression to exclude, with certainty, the possibility of the entry of liquid droplets into the compressor. Otherwise the compressor would be damaged by the impact of liquid droplets. By means of liquid sub-cooling the vapour portion is reduced at the inlet to the evaporator. Hence, more evaporation heat can be absorbed.




Figure 6- Pressure-enthalpy diagram of an ideal refrigeration cycle.




Figure 7- p - h diagram of a real refrigeration cycle.

To calculate the refrigerating capacity, i.e., heat transfer from low temperature source, \dot{Q}_L , the refrigerant mass flow rate \dot{m} should be known beforehand. The specific volume ν for the refrigerant is read from the p-h diagram. Using the volumetric flow rate read on the volumetric flow meter, \dot{V} , the mass flow rate is calculated:

$$\dot{m} = \frac{\dot{V}}{\nu} \tag{1}$$

Consequently, the refrigeration capacity, \dot{Q}_L , is calculated as:

$$\dot{Q}_L = \dot{m} q_L = \dot{m} (h_1 - h_4)$$
 (2)

This value is identical to the heat which is transferred to the water cooled in the evaporator:

$$\dot{Q}_L = \dot{m}_{\rm w} C \left(T_{\rm in} - T_{\rm out} \right) \tag{3}$$

where $\dot{m}_{\rm w}$ is the water mass flow rate in the evaporator, C is the specific heat capacity of water, T_{in} and T_{out} are inlet and outlet temperatures of water in the evaporator, respectively. The compressor work $\dot{\rm W}$ can be taken from the cyclic process plotted in the p-h diagram. It is given by the enthalpy difference between the working fluid states before and after the compressor (points 1' and 2' in Fig. 6):

$$\dot{W} = \dot{m} \left(\mathbf{h}_2 - \mathbf{h}_1 \right) \tag{4}$$

Another important parameter in analysis of refrigerators is the coefficient of performance (COP). COP is the ratio of useful energy, i.e., heat transfer from low temperature source, \dot{Q}_L , to the costing energy, i.e., the energy consumption of the compressor, \dot{W} .

$$COP = \frac{\dot{Q}_L}{\dot{W}} \tag{5}$$

The COP can be greater than 1 because \dot{W} is the difference between the absorbed and the emitted heats. Therefore, the performance number must not be termed efficiency; efficiency is always less than 1.

It should be noted that in real cycles, energy consumption of the cycle is different from \dot{W} and is equal to energy consumption of the driving motor, P. Therefore, P should be used in Eq. (5) instead of \dot{W} .

A further parameter for a refrigeration system is the compressor compression ratio, ψ . This provides an indication of the increase in pressure that takes part in the compressor. It is given by the ratio of the upper and lower isobars for the cyclic process (see Fig. 8):

$$\psi = \frac{p_{2/3}}{p_{1/4}} \tag{6}$$

The compression ratio may affects the COP of a refrigeration cycle.




Figure 8- Pressure ratio on a p - h diagram of a refrigeration cycle.

Procedure

After the system is filled as described in previous sections, the subsequent procedure should be followed:

- 1. Close the hand valves 2 and 4
- 2. Open the hand valves 1 and 3
- 3. Start water flow through the system

- 4. Switch on compressor
- 5. Set the volumetric flow rate of the refrigerant, cooling and heating waters. Leave compressor to run for a while so that a steady state condition is reached in the system. Measure the temperatures T₁-T₈ and also read the pressure in the condenser and the evaporator, fill out Table 1. On reading the manometer 1 bar must be added to the value read to obtain the actual pressure.
- 6. Change the flow rate of the refrigerant, wait until the cycle reaches its steady-state condition, and repeat step number 5.

Using the p-h diagram of R141b provided in Appendix A and the measured data during the experiment draw thermodynamic cycles for the two tests. Then, calculate the pressure ratio, the refrigeration capacity and the COP of the cycle for each pressure ratio. Also, plot the COP and the refrigeration capacity versus the pressure ratio.

Table 1: Operating parameters vapor compression refrigeration cycle

Test #	T_1	T_2	T_3	T_4	T_5	T_6	T_7	T_8
1								
2								

Test #	Cooling Water	Heating Water	Refrigerant	Condenser	Evaporator	Compressor
	Flow Rate	Flow Rate	Flow Rate	Pressure	Pressure	Power
1						
2						

Discussion

- 1) What are the important characteristics of a refrigerant?
- 2) How pressure ratio variation affects the COP of refrigeration cycle?
- 3) When the state of the refrigeration locates in the saturation dome, how its state can be fixed?

Appendix A




Figure 9- p - h diagram of R141b