

Performance Evaluation of Low Pressure Evaporator with Low-finned Tubes for an Adsorption Cooling System

Presented by

Poovanna Thimmaiah

Co-authors

Amir Sharafian, Wendell Huttema, Majid Bahrami

*IVth International Symposium on
Innovative Materials for Processes in Energy Systems*


Sicily, Italy

October 26th, 2016

SFU


SIMON FRASER
UNIVERSITY
ENGAGING THE WORLD






- Water as an refrigerant
 - Operating pressure is very low (close to vacuum)
 - Low Pressure (LP) evaporator

- 5 cm of water height causes:




- ❑ The **hydrostatic pressure** should be minimized inside the **low operating pressure** evaporators
- ❑ A conventional evaporator fails to perform efficiently



- Falling film evaporation



Side view





Front view



Limitations:



- Equal distribution of refrigerant
- Internal pump (active pumping)
- Complex
- Higher weight

- ❑ Capillary-assisted evaporation
- ❑ Inspiration: Plants use capillary action to draw water from the ground



Advantages:



- ❑ Uniform evaporation rate along the circumference of the tube
- ❑ No parasitic energy consumption
- ❑ Lower weight
- ❑ No complexity



Dr. Wang
Shanghai Jiao Tong University of China

Dr. Lanzerath
RWTH Aachen University, Germany

Dr. Schnabel
Fraunhofer Institute for Solar Energy
Systems ISE, Germany



Tested tubes and fin structures

Industrial partners



Wieland Thermal Solutions., Germany



Wolverine Tube Inc., USA




Plain tube



Turbo Chil-26 FPI
(Wolverine Tube Inc.)



Turbo Chil-40 FPI
(Wolverine Tube Inc.)



Turbo ELP
(Wolverine Tube Inc.)




Turbo CLF-40 FPI
(Wolverine Tube Inc.)




Confidential-NDA
(Wieland Thermal Solutions)




GEWA-KS-40 FPI
(Wieland Thermal Solutions)








Plain Tube Vs. Finned tube



- The plain tube fails to maintain the evaporator heat transfer coefficient




- Maintains constant evaporator heat transfer coefficient




Chilled water mass flow rate : 2.5 LPM
Chilled water inlet temperature: 15°C

Smaller diameter finned tube





15 mm

40 FPI, 0.6 mm fin spacing




7.9 mm

26 FPI, 1 mm fin spacing





Partial capillary

Pooled water (colored)






Type - 2nd Generation (2G)






Chilled water inlet temp : 20°C
 Chilled water mass flow rate: 2.5 LPM

- In region I (tube is fully submerged)- overall U is about $1600 \text{ W}/(\text{m}^2\cdot\text{K})$.
- In region II- the hydrostatic pressure is reduced and the overall U increases by 45% from 1600 to $2320 \text{ W}/(\text{m}^2\cdot\text{K})$
- In region III, U decreases to $1720 \text{ W}/(\text{m}^2\cdot\text{K})$ as the water level drops further as capillary force fails to cover the entire surface.


Porous copper coated evaporator




- ❑ The porous copper coating from thermal spray deposition technology
- ❑ Deposition is compatible with the material of evaporator



SEM images of the porous coatings






Dry surface- Hydrophobic




Wetted surface- Enhances wicking


SFU Comparison between uncoated and coated evaporator








Uncoated



Coated



- ❑ The tube internal dia was reduced to increase the h_i (α_i)
- ❑ Porous copper coatings to improve the capillary evaporation.
- ❑ The overall U of the coated evaporator increased by 30%
- ❑ The cooling power of the coated evaporator improved by 2 times.





Natural Sciences and Engineering Research Council of Canada (NSERC)

Automotive Partnership Canada (APC)

Wieland

Dr. Karine Brand,
Dr. Achim Gotterbarm, Director Global R&D






Dr. Evraam Gorgy, Director of R&D
Mr. Bill Korpi
Wolverine Tube, Inc.

Black bear poses next to SFU sign in best advertising photo ever



Thanks for your attention
Questions/Comments

Why Design of Evaporator of an ACS is Different? Contd.




- All thermocouples have same reading at the beginning (Equilibrium State)
- Evaporator pressure reduces when the control valve is opened and remains constant until evaporator runs out of water
- For all calculations, data were extracted from demarcated region (Steady state)



Quantifying the evaporator performance

$$\frac{1}{UA} = \underbrace{\left(\frac{1}{h_o A_o} \right)}_{\text{External Resistance}} + \underbrace{\left(\frac{1}{h_i A_i} + R_{o, \text{finned tube}} \right)}_{\text{Internal Resistance}}$$


Material Resistance



$$R_{o, \text{finned tube}} = R_{\text{fin}} + R_{\text{wall}}$$



Future work



CALPE- Capillary Assisted Low Pressure Evaporator

